



advanced FLOW engineering Quantum Cold Air Intake System

Instruction Manual P/N: 54-13056S / 54-13056SL / 54-13056SR

Make: **Ford**

Model: **Ranger**

Year: **2019-2020**

Engine: **I4-2.3L (t)**




- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- For technical support please call 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A1	1	Scoop (Black)	05-54013056B3
A2	1	Scoop (Blue)	05-54013056L3
A3	1	Scoop (Red)	05-54013056R3

Installation will require the following tools:

T-30 Torx drive

Emissions Disclaimer: This product is not currently CARB exempt and is not available for purchase in California or for use on any vehicle registered with the California Department of Motor Vehicles.






Figure A

Refer to Figure A for Step 1

Step 1: Using a T30 Torx drive, remove the two screws①holding down the air scoop②. Remove the scoop and set aside.



Figure B

Refer to Figure B for Steps 2

Step 2: Install the aFe Dynamic Air Scoop using the two screws ③ removed in step 1. Tighten the screws.

NOTE: Check all screws are secure after 100-200 miles.







advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879